

Solution : Make Sure the Default Repository is Properly Configured in CentreWare Internet Services (CWIS)

Make sure the Default File Repository settings have not been changed in CentreWare Internet Services (CWIS). EFI Fiery Scanning does not use the Default File Repository in CWIS.

The Default File Repository in CWIS must have the following settings:

Protocol = FTP
Host Name / IP address and Port = 100.100.100.102: 21
File Path = . (period)
Login Credentials to Access the Destination = System
Login Name = template
Password = fX7eWp1a7e (case sensitive)

Template Pool Setup:

Protocol = FTP
Host Name / IP address and Port = 100.100.100.102: 21
Login Name = template
Password = fX7eWp1a7e (case sensitive)

To configure the File Repository Settings in CWIS:

Open an Internet browser window.

Enter the IP address of the printer in the Address field, and then press [Enter] on the keyboard.

Click on the [Xerox CentreWare] button in the lower right corner.

If prompted, enter the username and password in the fields provided, and then click [OK]. The CentreWare Internet Services window will be displayed.

NOTE: The default username is "admin" and the default password is "1111". If the username or password has been modified or forgotten, contact your System Administrator.

Click on the [Properties] tab.

Configure the Default File Repository:

Click on the [Services] link on the left side of the window.

Click on the [Network Scanning] link.

Click on the [File Repository Setup] link. The File

Repository Setup information will be displayed.

Click on the [Edit] button in the File (Default) section.
The Default file repository settings will be displayed.

Leave the Friendly Name field blank.

Select [FTP] from the Protocol pull-down menu.

Type: 100.100.100.102 in the Host Name / IP Address &
Port field.

Type: 21 in the Port field. The Port field is located
after the colon (:).

Type a period (.) in the File Path field. Select
the [System] radio button from the Login
Credentials to Access the Destination field.

Type: template (case sensitive) in the Login Name fie
ld. Type: fx7ewp1a7e (case sensitive) in the Password
and Retype Password fields.

Click on [Apply] to save the changes.

Configure the Template Pool:

Click on the [Advanced] link on the left side of the
window.

Click on the [Template Pool Setup] link. The Template Poo
l Setup window will be displayed.

Select [FTP] from the Protocol pull-down menu.

Type: 100.100.100.102 in the Host Name / IP Address &
Port field.

Type: 21 in the Port field. The Port field is located
after the colon (:).

Type a period (.) in the File Path field.

Type: template (case sensitive) in the Login Name fie
ld. Type: fx7ewp1a7e (case sensitive) in the Password
and Retype Password fields.

Click on [Apply] to save the changes.

Restart the Fiery Server and the printer.